

Dashboard Screen for Tesla Model 3 (2017-2023) and Tesla Model Y 2021+

Green Drive Tesla Accessories Shop

If you have any questions please contact : support@greendrive-accessories.com

Table of Contents

Navigation Bar	01
Dashboard	02
Phone Connection	03
Setting	04
OTA	05
Installation steps Intel chip	06
Installation steps AMD Ryzen Chip	07


User Manual

Navigation Bar



Quickly locate the main panel

Swiping the right edge of the device screen to the left side, will pop up the navigation bar. touching the icon will directly go to the panel.



By using the right steering wheel to roll up and down, the switching elect can also be triggered




Navigation Bar will hide automatically If there is no operation after 5 seconds
If the screen in power off, touch the screen and hold 1 seconds to turn the screen alive

01 / 07

Dashboard




Overview



Appearance

In the **Setting > Appearance**, We can choose "Day / Night / Auto" by select "Auto", system will match the style from your car



Day / Light

Night / Dark

Volume & Brightness

You can switch diferent status by **Slide Up & Slide Down**
Left side control volume, Right side control brightness



User Manual

Main Stage

You can switch different status by **Slide Left & Slide Right**
Such as: **Parked** (Frunk & Trunk & Door) / **Driving** / **Tire Pressure**




Swipe Area (Red Part)

User Manual


Setting



Overview



Go Back



Swipe Area (Red Part)

02 / 07


Phone Connection



Overview

How to use

Type Switcher



CarPlay

A-Auto

CarLife


Full compatible with multiple platforms

03 / 07

Steering Wheel Roller


CarPlay

In the **General > Wheel Roller**, When you turn it on, You can use Wheel button to control the navigation of CarPlay




Phone Connection Display Mode

In the **Display > Split Screen**, by choosing **Full / Half** to switch the screen size for Phone Connection



Full Screen




Half Screen

Installation steps

Intel chip



1. Removal of the instrument panel (left side)



2. Removal of the dashboard (right side)




3. Raise the instrument panel vertically upward from the left and right sides



4. Remove the dashboard trim panel



5. Plug the power cord into the 37th and 39th holes counting from left to right, blind holes do not count in the count. Insert the machine into the dashboard trim panel by aligning the holes




6. Fixed mounting iron plate



7. Pry open the trim panel clips at the bottom of the glove box at the passenger side



8. Pull out the bottom flap of the glove box



9. Unplug the gray plug of the original car computer


Steering Wheel can not work with Autopilot

OTA



Overview

In the **Setting > Software**, You can easily check your system version, using OTA to get the latest update package, or switch to other theme as your favours.



Software


Let's Keep Your Dashboard Always Fresh & Safety




WE REALLY HOPE YOU CAN ENJOY IT!

Installation steps

Intel chip



10. Connect the unplugged computer plug B2 to the instrument screen power cable B2 plug




11. Connect the B1 end of the original car computer to the instrument screen power cable B1 plug



12. Wire interface description diagram




13. After connecting A and A1, put it through the position pointed out by the finger and fix the power cord with adhesive tape, which cannot block the position of the snap



14. Use tape to secure the power cable along the dashboard recess, toward the steering wheel. This is done to prevent rattling.



15. Connect the dashboard trim panel with the product installed to the power supply




16. After installing the trim panel, restore the front right A-pillar trim panel to its original state



17. Installation completed

Installation steps

Intel chip



1. Removal of the instrument panel (left side)



2. Removal of the dashboard (right side)



3. Raise the instrument panel vertically upward from the left and right sides



4. Remove the dashboard trim panel



5. Plug the power cord into the 37th and 39th holes counting from left to right, blind holes do not count in the count. Insert the machine into the dashboard trim panel by aligning the holes




6. Fixed mounting iron plate



7. Pry open the trim panel clips at the bottom of the glove box at the passenger side



8. Pull out the bottom flap of the glove box



9. Unplug the gray plug of the original car computer


User Manual

Installation steps

AMD Ryzen Chip



1. Removal of the instrument panel (left side)



2. Removal of the dashboard (right side)




3. Raise the instrument panel vertically upward from the left and right sides




4. Remove the dashboard trim panel



5. Plug the power cord into the 37th and 39th holes counting from left to right, blind holes do not count in the count. Insert the machine into the dashboard trim panel by aligning the holes



6. Fixed mounting iron plate



7. Remove the front right seat A-pillar flap



8. Blue Protocol Interface A



9. White power connector B

User Manual

Installation steps


Intel chip



10. Connect the unplugged computer plug B2 to the instrument screen power cable B2 plug




11. Connect the B1 end of the original car computer to the instrument screen power cable B1 plug



12. Wire interface description diagram




13. After connecting A and A1, put it through the position pointed out by the finger and fix the power cord with adhesive tape, which cannot block the position of the snap



14. Use tape to secure the power cable along the dashboard recess, toward the steering wheel. This is done to prevent rattling.



15. Connect the dashboard trim panel with the product installed to the power supply



16. After installing the trim panel, restore the front right A-pillar trim panel to its original state



17. Installation completed

06 / 07

Installation steps

AMD Ryzen Chip




10. After unplugging the original power connector B, connect the female connector to B1 and the male connector to B2



11. The effect after the power cord is connected is shown in the figure




12. Wire interface description diagram




13. Connect the blue protocol cable A1 to the original A connector




14. After connecting D and D1, put it through the position pointed out by the finger and fix the power cord with adhesive tape, which cannot block the position of the snap



15. Use tape to secure the power cable along the dashboard recess, toward the steering wheel. This is done to prevent rattling



16. Connect the dashboard trim panel with the product installed to the power supply



17. After installing the trim panel, restore the front right A-pillar trim panel to its original state



18. Installation completed

07 / 07